



Adapt Spyder Bolts

1. **Always use anti-seize or low/blue threadlock with titanium bolts to prevent galling.**
2. Torque bolts, using a calibrated torque wrench, to 20 ft-lbs. (If your torque wrench goes over 50 ft-lbs it is too big and should not be used for this application.)
3. **Absolutely, never use an impact gun on titanium bolts.**

Please email info@firenice.us if there is any issue with your order.